



ALL ADVANCE TECHNOLOGY MACHINES

DOUBLE DRUM ROLLER



Vibratory Frequency	70 Hz
Grade Ability	30%
Centrifugal Force	20 KN
Water Tank Capacity	20 Ltr
Drum Size (Dia X W)	425 X 600 MMx2
Engine(Diesel) / Power	Greaves 1510 Electric Start with Amron Battery
Max Travelling Speed	0 - 4 KM/H
Transmission System	Hydraulic
Weight	550 Kg



Operating Instructions:

1. Greasing should be done every 10 Days at the points mentioned in the Roller with the Grease Gun.
2. Clean the Roller on Daily Basis after completing the work.
3. Engine to be serviced after every 200 Hours of Use. Engine Oil to be Changed and Oil Filter to be cleaned or Replace it if damaged.
4. Hydraulic Oil to be changed after 6 months.
5. Hydraulic Oil filter also need to Cleaned on regular intervals or to be replaced if damaged.
6. Start Key should be on ON position after ignition of engine in order to charge the battery.
7. The Lever in Forward direction will move the roller in Forward Direction
8. The Lever in Backward direction will move the roller in Backward Direction.
9. The lever in Center Position will make the roller in neutral Position (The engine will be in working mode, but the roller will not move.)
10. In order to increase the speed pull the lever in forward direction and simultaneously to decrease the speed pull the lever backwards.
11. In order to shut the Engine, the speed of roller shall be reduced gradually and once the roller comes to Halt , PULL the the stop Lever in the Engine.

If you have any query please feel free to Contact us +919702455496.

Thanks & Regards
Rohan Gala.