



Quick Jumper Reference Page



Front Panel Connector (J12)

Your chassis will usually come with connectors to install onto the motherboard, such as HDD and Power LEDs. The Front Panel Connector (J12) has been implemented for such purposes.



CMOS Reset (J21)

1 2 3 1,2: Default

2,3: Connect these two pins together to reset the CMOS settings in case an incorrect setting causes system instability or you have forgotten your system/setup password of have just flashed your BIOS.

- Power off the system and disconnect the power supply from the motherboard.
- Close pins 2 and 3 on J21
- Wait about 5 seconds
- Close pins 1 and 2 on J21
- Reconnect the power supply and power on the system