

## **ORGANOID® WALLPAPER FLAX BACKING PROCESSING INSTRUCTIONS**

Technique: Wall-pasting technique  
To be installed with roll-on glue

- ⇒ Keep flax backing dry and clean
- ⇒ Apply wall paper paste to the wall!
- ⇒ Insert wallpaper into paste bed
- ⇒ Press firmly using a rubber roll

Surface: clean, dry, even, dust-free, absorbent, stable

Joints: double cut, leave 2 cm overlap

Recommended glue: AURO Universalkleber Nr. 380 (natural glue)  
Pufas Sicherheits-Kleister SK  
Pufas Glasgewebe- und Vlieskleber GK  
Universal glue for heavy wallpapers

We hope you are enjoying your Natural Wallpaper  
manufactured by Organoid Technologies GmbH